

Chapter 4 Ignition system

Contents

Coil - description and polarity	7	Distributor - removal, installation and ignition timing
Condenser (capacitor) - removal, testing and refitting	4	General description
Contact breaker - adjustment and lubrication	2	Ignition system - fault diagnosis
Contact breaker points - removal and refitting	3	Spark plugs and HT leads
Distributor - overhaul	6	

Specifications

System		6 volt negative earth. Coil ignition
Early 1500		12 volt negative earth. Coil ignition
All other models		

Firing order	1 - 3 - 4 - 2
----------------------------	---------------

Distributor

Type:		Bosch IFUR 4
All models except 1502, 2002 TI and 2002 TII		Bosch JF4D4
1502		Bosch IFR 4
2002 TI		Bosch IFDR 4
2002 TII		Clockwise
Rotational direction		0.016 in. (0.4 mm)
Contact breaker gap		
Dwell angle:		59 to 61°
1500/1600		59 to 65°
1502		61 to 65°
1602		59 to 65°
2000/2002 except TI		59 to 61°
2002 TI		
Static ignition timing:		3° BTDC
All models except 2002 TI and 2002 TII		TDC
2002 TI and 2002 TII		
Dynamic ignition timing:		25° BTDC @ 1400 rpm
All models except 1502, 2002 TI and 2002 TII		25° BTDC @ 1900 rpm
1502		25° BTDC @ 2200 rpm
2002 TI		25° BTDC @ 2400 rpm
2002 TII		25° BTDC @ 2000 rpm
2002 with emission control and air pump		
Maximum centrifugal advance:		18°
1500/1600/1602		16°
2002		2 to 6°
2002 (automatic transmission)		16°
2002 TI and TII		
Maximum vacuum advance:		4 to 6°
All models except 1502		10°
1502		
Ignition advance (engine at operating temperature, vacuum pipe disconnected):		
Rpm	1502	1500/1600/1602
1000	5 to 10°	23 to 27°
1500	—	25 to 29°
2000	26 to 30°	30 to 34°
2500	32 to 37°	34 to 38°
2700	—	—
3000	34 to 38°	38 to 42°
3500	—	40 to 44°
3800	—	42 to 46°
4000	38 to 45°	—
		2002
		21 to 25°
		26 to 30°
		31 to 35°
		36 to 40°
		38 to 42°

Rpm	2002 Auto. transmission	2002 T1	2002 TII
1000	11 to 15°	18 to 22°	2 to 7°
1500	17 to 21°	23 to 27°	12 to 17°
2000	23 to 27°	28 to 32°	18 to 22°
2500	30 to 33°	33 to 37°	24 to 28°
2700	—	35 to 39°	—
3000	37 to 41°	—	28 to 32°
3500	41 to 45°	—	30 to 34°
3800	42 to 46°	—	—
4000	—	—	—
Vacuum advance starts between	—	4.72 and 5.91 in Hg. (120.0 and 150.0 mm Hg)	—
Vacuum advance ends between	—	7.68 and 8.27 in Hg. (195.0 and 210.0 mm Hg)	—

Coil

Type:

1500

Early 6V ...

Later 12V ...

1502/1600/1602 ...

2002 ...

2002 (automatic transmission) ...

2002 T1 and 2002 TII ...

Bosch TE6B4

Bosch TE12V

Bosch TE12V

Bosch KW12V

Bosch KW12V

Bosch K12V

*Check Cap + Rotor**13/16" Socket**Plugs**NGK BP6ES***Condenser**

Capacity ... 0.23 to 0.32 uf

Spark plugs

Type:

1502

1500/1600/
1602

2002

2002 Auto.
Transmission

2002 T1

2002 TII

Bosch ... W145T30

W200T30

W200T30

W200T30

W200T30

WG200T30

W175T30*

W175T30*

W175T30*

Beru ... —

200/14/3A

200/14/3A

200/14/3A

200/14/3A

G200/14/3

175/14/3A*

175/14/3A*

175/14/3A*

Champion ... —

N8Y

N8Y

N8Y

N8Y

N9Y

N9Y*

* Used with 9.5 : 1 compression ratio and in engines with redesigned combustion chambers marked E12 on cylinder head.

Spark plug gap ... 0.024 to 0.028 in (0.6 to 0.7 mm)

*0.033***Torque wrench settings**

Spark plugs ... lb/ft

Nm

22

30

1 General description

In order that the engine can run correctly it is necessary for an electrical spark to ignite the fuel/air mixture in the combustion chamber at exactly the right moment in relation to engine speed and load. The ignition system is based on feeding low tension (LT) voltage from the battery to the coil where it is converted to high tension (HT) voltage. The high tension voltage is powerful enough to jump the spark plug gap in the cylinders many times a second under high compression pressures, providing that the system is in good condition and that all adjustments are correct.

The ignition system is divided into two circuits. The low tension circuit and the high tension circuit.

The low tension (sometimes known as the primary) circuit consists of the battery lead to the control box, lead to the ignition switch, lead from the ignition switch to the low tension or primary coil windings (terminal +), and the lead from the low tension coil windings (coil terminal -) to the contact breaker points and condenser in the distributor.

The high tension circuit consists of the high tension or secondary coil windings, the heavy ignition lead from the centre of the coil to the centre of the distributor cap, the rotor arm, and the spark plug leads and spark plugs.

The system functions in the following manner. Low tension voltage is changed in the coil into high tension voltage by the opening and closing of the contact breaker points in the low tension circuit. High tension voltage is then fed via the carbon brush in the centre of the distributor cap to the rotor arm of the distributor cap, and each time it comes in line with one of the four metal segments in the cap, which are connected to the spark plug leads, the opening and closing of the

contact breaker points causes the high tension voltage to build up, jump the gap from the rotor arm to the appropriate metal segment and so via the spark plug lead to the spark plug, where it finally jumps the spark plug gap before going to earth.

The ignition is advanced and retarded automatically, to ensure the spark occurs at just the right instant for the particular load at the prevailing engine speed.

The ignition advance is controlled both mechanically and by a vacuum operated system. The mechanical governor mechanism comprises two weights, which move out from the distributor shaft as the engine speed rises due to centrifugal force. As they move outwards they rotate the cam relative to the distributor shaft, and so advance the spark. The weights are held in position by two light springs and it is the tension of the springs which is largely responsible for correct spark advancement.

The vacuum control consists of a diaphragm, one side of which is connected via a small bore tube to the carburettor, and the other side to the contact breaker plate. Depression in the inlet manifold and carburettor, which varies with engine speed and throttle opening, causes the diaphragm to move, so moving the contact breaker plate, and advancing or retarding the spark. A fine degree of control is achieved by a spring in the vacuum assembly.

On cars equipped with an exhaust emission control system, a speed sensitive relay, solenoid valve and carburettor dashpot are used to regulate the operation of the distributor advance vacuum circuit to minimise the emission of fumes during certain operational conditions particularly during deceleration with the accelerator pedal released. Refer to Chapter 3, Fig. 3.33. On all models a resistor is fitted as standard in the coil primary circuit to prevent voltage drop and difficult starting when the starter motor is actuated.