
MANUAL
1240-00
AEGS
FRONT POWER DISTRIBUTION BOX
.5 SW/BR
2.5 SW/GE
2.5 SW/GE
.5 SW/BR
X55
B900 JUMPER PLUG
K1 STARTER RELAY
30
86
87
85
SW
.5 BR/SW
X215
GROUND DISTRIBUTION
1.5 BR/SW
X165
2.5 SW/GE
18
X20
D100 DIAGNOSTIC CONNECTOR
11
X1532
X1902
CHARGING SYSTEM
16 SW
.75 SW/GN
3
1 SW/GN
X79
50
30h
30
M1 STARTER
31
.75 SW/GN
.5 SW/GN
X36
X34
.5 SW/GN
.5 SW/GE
12
10
X501
X190
25
X14
.5 SW/GN
N4 ON-BOARD COMPUTER
2
X74
19
X613
A11 AUTOMATIC HEATING AND AIR CONDITIONING CONTROL UNIT (IHKA)
19
X255
A1 GENERAL MODULE
16
A12 DIAGNOSTIC MODULE (SRS)