

For vehicles with automatic gearbox:
 Item Nos. 27-53-X (2x): Starter lock switch (17)
 and all associated cables
 For TILUX: Revolution counter and heated rear
 window are standard equipment (clock in com-
 bined instrument)

Special Equipment only:

Item Nos. 4-7-19-20 (foglamps)
 41-54 (heated rear window)*
 47-48-49 (radio and aerial)
 45 (Revolution counter in place
 of clock)*

* Not TILUX

Cable coding:

1.5 sq. mm cross-section

Basic colour:

BL = blue

BR = brown

GE = yellow

GN = green

GR = grey

RT = red

SW = black

WS = white

- 57 Number plate light
 58 Rear light LH
 X Flat pin connector
- Instruments:**
- a Instrument lighting
 - b Fuel gauge
 - c Thermometer
 - d Main beam telltale (blue)
 - e Fuel reserve and choke telltale (white)
 - f Turn indicator telltale (green)
 - g Oil pressure telltale (orange)
 - h Charge telltale (red)

Rear lights:

A = Turn indicator
 B = Reversing lights
 C = Rear lights
 D = Stop lights

Ignition / starter switch:

I Halt
 II Garage
 III Fahrt (Drive)
 IV Start

Firing order: 1-3-4-2

- 29 Screenwiper motor
 30 Delay relay
 31 Heater blower motor
 32 Cigar lighter
 33 Choke cable switch
 34 Screenwiper switch
 35 Heater switch
 36 Ignition/starter switch
 37 Turn indicator/parking light/
 screenwasher switch
 38 Horn ring
 39 Light switch
 40 Dip switch
 41 Switch for heated rear window
 42 Combined instrument
 43 Speedometer
 44 Clock
 45 Revolution counter
 46 Flasher unit
 47 Separate fuse for radio
 48 Aerial
 49 Radio
 50 Door switch RH
 51 Door switch LH
 52 Interior light
 53 Selector lever illumination
 54 Heated rear window
 55 Fuel gauge tank mechanism
 56 Rear light RH
- 1 Turn indicator front RH
 2 Parking light RH
 3 Headlight RH
 4 Foglamp RH
 5 Horn RH
 6 Horn LH
 7 Foglamp LH
 8 Headlight LH
 9 Parking light LH
 10 Turn indicator front LH
 11 Soldered joint
 12 Horn relay
 13 Voltage regulator
 14 Alternator
 15 Starter
 16 Battery
 17 Switch for reversing light and starter lock
 18 Stop light switch
 19 Foglamp switch
 20 Foglamp relay
 21 Distributor
 22 Coil
 23
 24 Oil pressure contact
 25
 26 Starter relay
 27 Fuse box
 28 Screenwasher pump